




Rear mount sockets for 230M and 230E runners in frame cabinets


Synthetic, neutral color

Attach with Blum 612TH screws. #6 x 1/2" trusshead

Cannot be used with 430 full extension series

Part No. 230M RH & LH Socket Set 230M RH 230M LH





Cabinet profile spacers

To space runners away from the cabinet side to clear door protrusion on interior roll-out trays.

Two thicknesses available that can be stacked up to 24 (15/16")

Synthetic, neutral color

Part No. **A** 8 (5/16") with Ø5 (3/16") x 11 dowel for linebore mounting

B 4 (5/32") stackable

320M0048


© 8 (5/16") stackable

320M0088

Heavy duty spacer Synthetic, neutral color

(D) 32 (1-1/4") x 19 (3/4")

602750



penetrates cabinet side at least 13 (1/2")

Heavy duty spacer Use 3 deep thread system screws to attach runner to spacer and spacer to cabinet side

spacers on front, middle and rear of each cabinet profile for adequate support.


Door protectors

For pull-out surrounds to prevent damage to doors.


Fixed to the underside of the drawer. For 230M and 430E runners. Symmetrical. Epoxy coated steel, with synthetic rollers, cream color.

Door protector

Part No. 298.2200 Space requirements



Assembly



Screws and bumpers

#6 x 1/2", #2 Phillips

Deep thread wood screws *⊲umm* Nickel plated Part No. #6 x 5/8", #2 Phillips 606N #6 x 5/8", #2 POZI 606P η Zinc plated Part No.

Deep thread system screws Pilot bore Ø5 (3/16") hole

Nickel plated

Part No. 11.5 (7/16"), #2 POZI 661.1150 661.1300 13 (1/2"), #2 POZI

Drawer bumper stops Cushions drawer closing Self-adhesive back, clear



6 (1/4") dia. x 1.5 (1/16") thk. 10 (3/8") dia. x 3 (1/8") thk.

Part No. FX4041

